

WATCH FULL COLOR VIDEO ON GAME BOY ADVANCE!

GAME BOY ADVANCE

AGB-MNCE-USA

video



NICK

**NICKTOON'S
COLLECTION
Volume 1**

Official
Nintendo
Seal

MAJESCO

The official seal is your assurance that this product is licensed or manufactured by Nintendo. Always look for this seal when buying video game systems, accessories, games and related products.

Nintendo does not license the sale or use of products without the Official Nintendo Seal.



THIS VIDEO PAK WILL WORK ONLY WITH THE GAME BOY® ADVANCE VIDEO GAME SYSTEM.

LICENSED BY



NINTENDO, GAME BOY, GAME BOY ADVANCE VIDEO AND THE OFFICIAL SEAL ARE TRADEMARKS OF NINTENDO. © 2004 NINTENDO.

Important Legal Information

Copying of any video pak for any Nintendo system is illegal and is strictly prohibited by domestic and international intellectual property laws. "Back-up" or "archival" copies are not authorized and are not necessary to protect your software. Violators will be prosecuted.

This video pak is not designed for use with any unauthorized copying device or any unlicensed accessory. Use of any such device will invalidate your Nintendo product warranty. Nintendo (and/or any Nintendo licensee or distributor) is not responsible for any damage or loss caused by the use of any such device. If use of such device causes your video pak to stop operating, disconnect the device carefully to avoid damage and resume normal play. If your video pak ceases to operate and you have no device attached to it, please contact the video pak publisher's "Technical Support" or "Customer Service" department.

The contents of this notice do not interfere with your statutory rights. This booklet and other printed materials accompanying this video pak are protected by domestic and international intellectual property laws.

Rev-D (L)

IMPORTANT SAFETY INFORMATION: READ THE FOLLOWING WARNINGS BEFORE YOU OR YOUR CHILD PLAY VIDEO GAMES

⚠ WARNING - Seizures

- Some people (about 1 in 4000) may have seizures or blackouts triggered by light flashes or patterns, such as while watching TV or playing video games, even if they have never had a seizure before.
- Anyone who has had a seizure, loss of awareness, or other symptom linked to an epileptic condition should consult a doctor before playing a video game.
- Parents should watch when their children play video games. Stop playing and consult a doctor if you or your child have any of the following symptoms:

Convulsions

Altered vision

Eye or muscle twitching

Involuntary movements

Loss of awareness

Disorientation

To reduce the likelihood of a seizure when playing video games:

1. Sit or stand as far from the screen as possible.
2. Play video games on the smallest available television screen.
3. Do not play if you are tired or need sleep.
4. Play in a well-lit room.
5. Take a 10 to 15 minute break every hour.

⚠ WARNING - Repetitive Motion Injuries and Eyestrain

Playing video games can make your muscles, joints, skin or eyes hurt after a few hours. Follow these instructions to avoid problems such as tendinitis, carpal tunnel syndrome, skin irritation or eyestrain:

- Avoid excessive play. It is recommended that parents monitor their children for appropriate play.
- Take a 10 to 15 minute break every hour, even if you don't think you need it.
- If your hands, wrists or arms or eyes become tired or sore while playing, stop and rest them for several hours before playing again.
- If you continue to have sore hands, wrists or arms or eyes during or after play, stop playing and see a doctor.


⚠ WARNING - Battery Leakage

Leakage of battery acid can cause personal injury as well as damage to your Game Boy. If battery leakage occurs, thoroughly wash the affected skin and clothes. Keep battery acid away from your eyes and mouth. Leaking batteries may make popping sounds.

To avoid battery leakage:

- Do not mix used and new batteries (replace all batteries at the same time).
- Do not mix alkaline and carbon zinc batteries.
- Do not mix different brands of batteries.
- Do not use nickel cadmium batteries.
- Do not leave used batteries in the Game Boy. When the batteries are losing their charge, the power light may become dim, the game sounds may become weak, or the display screen may be blank. When this happens, promptly replace all used batteries with new batteries.
- Do not leave batteries in the Game Boy or accessory for long periods of non-use.
- Do not leave the power switch on after the batteries have lost their charge. When you finish using the Game Boy, always slide the power switch OFF.
- Do not recharge the batteries.
- Do not put the batteries in backwards. Make sure that the positive (+) and negative (-) ends are facing in the correct directions. Insert the negative end first. When removing batteries, remove the positive end first.
- Do not dispose of batteries in a fire.

GAME BOY® ADVANCE SP
[These functions also work with
the Game Boy Advance system.]



Getting Started

To get started with your Game Boy® Advance Video pak, please begin with the following:

- Make sure your Nintendo® Game Boy® Advance is turned off, then insert the *Nicktoon's Collection* Video pak into the Nintendo® Game Boy® Advance.
 - Turn on your Game Boy® Advance. In a few moments the Title Screen appears. You can bypass this by pressing the A Button or just wait until it transitions into the Episode Selection Screen.
 - At the Episode Selection Screen, use the Control Pad Up and Down to cycle through available episodes then press the A Button to select the one you want to watch. Then just sit back and enjoy the show!
- * *The Button lock feature lets you prevent accidental button presses that can interrupt video viewing.*
- ** *Avoid pressing the Fast Forward or Rewind Buttons while paused.*

TOKYOPOP®

WHAT HAPPENS WHEN FAIRY
GODPARENTS GET A LITTLE ODD?



FIND OUT IN
THE NEW



The Fairy Godparents!
od Parents!

NICKELODEON
CINE-MANGA

Available now at
bookstores near you!



TOKYOPOP

BUSTIN' OUT FROM BIKINI BOTTOM!



SPONGEBOB'S GOT HIS OWN CINE-MANGA™




Available now at bookstores near you!

©2004 Viacom International Inc. All rights reserved. Nickelodeon, SpongeBob SquarePants and all related titles, logos and characters are trademarks of Viacom International Inc. ©2004 TOKYOPOP Inc.



www.TOKYOPOP.com

NICKELODEON



© 1997 Nickelodeon Entertainment Co. All Rights Reserved. Nickelodeon, The Adventures of Jimmy Neutron, Boy Genius, The Fairy Ood Parents!, All Grow Up!, SpongeBob SquarePants and all related names, logos and characters are trademarks of Nickelodeon Entertainment Co. SpongeBob SquarePants created by Stephen Hillenburg. The Fairy Ood Parents created by Brian B. Cohen. Nickelodeon All Stars on Full created by Minsky Group, Inc.

You can look for all your
favorite Nicktoons on
Game Boy® Advance Video!!



www.gba-video.com

Nick.com

GBA Video Pak Production Credits

MAJESCO

Chief Technical Officer

Kevin B. Ray

Executive VP

Joseph Sutton

VP of Development

Dan Kitchen

VP of Marketing

Ken Gold

Director of Creative Services

Leslie Mills

Product Manager

Liz Buckley

IT Manager

Paul Campagna

Marketing Assistant

Matthew Ciccone

Art & Packaging

Tavio Castrillo

Keith Patrick

Special Thanks

Morris Sutton

Jesse Sutton

Adam Sutton

Additional Engineering

Marc Reynolds

DC STUDIOS

Executive Producer

Mark Greenshields

Producer

Stephane Roy

Programmer

Alexandre Ganea

Art

Bobbi Burquel

Test

Lon Benattar

Simon Graveline

GAME BOY ADVANCE Video

Majesco Sales, Inc. warrants to the original consumer purchaser that this Nintendo Video Pak (PAK) shall be free from defects in material and workmanship for a period of 90 days from date of purchase. If a defect covered by this warranty occurs during the 90 day warranty period, Majesco Sales, Inc. will repair or replace the PAK, at its option, free of charge.

To receive this warranty service:

1. DO NOT return your defective Video Pak to the retailer.
2. Notify Majesco Sales, Inc. of the problem requiring warranty service by calling our Technical Support Department at (800) 826-0015, and leave a message.
3. If the Majesco Sales, Inc. Service Representative is unable to solve the problem by phone, you will be provided with a Return Authorization number. Simply record this number on the outside packaging of your defective PAK, enclose your name, address and phone number, and return your PAK, freight prepaid and insured for loss or damage, together with your sales slip or similar proof of purchase (LPC code) within the 90-day warranty period to:

Majesco Sales, Inc.
160 Paritan Center Parkway (Suite 1)
Edison, NJ 08837

This Warranty shall not apply if the PAK has been damaged by negligence, accident, unreasonable use, modification, tampering, or other causes unrelated to defective materials or workmanship.

Repairs/Service after Expiration of Warranty

If the PAK develops a problem requiring service after the 90 day period, you may contact the Majesco Sales, Inc. Technical Support Dept. at the phone number noted earlier. If the Majesco Sales Dept. is unable to solve the problem over the phone, you may be informed of the approximate cost for Majesco Sales, Inc. to repair or replace the PAK, and provided with a Return Authorization number. Record this number on the outside packaging of the defective PAK and return the merchandise, **FREIGHT PREPAID AND INSURED FOR LOSS OR DAMAGE**, to Majesco Sales, Inc., and enclose a money order payable to Majesco Sales, Inc. for the cost quoted to you. If after personal inspection, the Majesco Sales, Inc. Service Representative determines the PAK cannot be repaired, it will be returned and your payment refunded.

Warranty Limitations

ANY APPLICABLE IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY LIMITED TO NINETY DAYS FROM THE DATE OF PURCHASE AND ARE SUBJECT TO THE CONDITIONS SET FORTH HEREIN. IN NO EVENT SHALL MAJESCO SALES, INC. BE LIABLE FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES RESULTING FROM THE BREACH OF ANY EXPRESS OR IMPLIED WARRANTIES.

The provisions of this warranty are valid in the United States only. Some states do not allow limitations on how long an implied warranty lasts or exclusion of consequential or incidental damages, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

For all of the latest news
on Game Boy Advance Video,
drop by www.GBA-Video.com.



While you're there, make sure you register for our newsletter so you can stay updated on content additions and announcements relating to this exciting new product!



www.GBA-Video.com

© 2004 Viacom International Inc. All Rights Reserved. Nickelodeon, The Adventures of Jimmy Neutron, Boy Genius, The Fairly OddParents, Nickelodeon All Grown Up!, SpongeBob SquarePants and all related titles, logos and characters are trademarks of Viacom International, Inc. SpongeBob SquarePants created by Stephen Hillenburg. The Fairly OddParents created by Butch Hartman. Nickelodeon All Grown Up! created by Klasky Csupo, Inc. Majesco Sales Inc., 160 Raritan Center Parkway, Edison, New Jersey 08837

PRINTED IN USA