

NEO TURF MASTERS

© 1996 NAZCA CORPORATION.

Aim at a Grand Slam!
A real full-scale Golf Game is now available !!

How to play with NEO TURF MASTERS



lever

up/down : you can select a club
right/left : you can choose the
direction of your shot

shot/pat

hook&slice



NEOGEO is a trademark of SNK Corporation. Printed in Japan.

*D is an unused button

■ NEO TURF MASTERS SOFT DIP SETTINGS ■

Page 1 Initial Settings Screen

NEO TURF MASTERS	
▶ TIME	00m 30 s
HOLE(1st)	3
HOLE(continue)	3
MATCH PLAY HOLE	WIN + / LOS -
CONTINUE	ON
DIFFICULTY	LEVEL 4
▼NEXT PAGE	

Page 2 Initial Settings

NEO TURF MASTERS	
▶ PLAY MANUAL	ON
DEMO SOUND	WITH
CREDIT/LEVEL	ON/ON
LANGUAGE	ENGLISH

How to operate: ① Use the Joystick to move cursor up or down to items you want to change.
 ② Press A Button to proceed to new settings and set selections.
 (Press B Button to return to previous settings.)

[TIME] Set the time allowed per shot.
Factory Setting: 30 seconds (1 second - 29 minutes 59 seconds possible.)
[HOLE(1st)] Set the number of holes for the first 1 credit.
Factory Setting: 3 Holes/credit (1 hole/credit - 99 holes/credit possible.)
[HOLE(continue)] Select the number of holes per continue.
Factory Setting: 3 Holes/continue (1 hole/continue - 15 holes/continue possible.)
[HOLE PENALTY] Select penalty per hole.
Bogey → Per → Give Up → No Penalty
[MATCH PLAY HOLE] Set the 1 hole gain or loss for winning or losing in 2 player match play.
WIN +/LOS - → WIN 0/LOS 0 → WIN 0/LOS - → WIN +/LOS 0
[CONTINUE] Set the Continue Play option.
ON → OFF
[DIFFICULTY] Set the game's difficulty level.
Factory Setting: 4 (1-8 possible.)
[PLAY MANUAL] Turn on or off the play instructions.
ON → OFF
[DEMO SOUND] Set sound during demonstration screens.
WITH → WITHOUT
[CREDIT / LEVEL DISPLAY] Set credit and level display.
ON/ON → ON/OFF → OFF/ON → OFF/OFF
[LANGUAGE] Change language. (Only for Europe or Asia.)
ENGLISH → SPANISH → PORTUGUESE